

## Supplemental Instructions for XP/White Bracket

**Mounting the spray arm on the XP style Keeton bracket requires a small modification to the spray arm. Please complete these steps before attempting to mount the arm to bracket.**



Step 1: Using a sharp utility knife trim the point off of the top of the spray arm as shown here. You can also use a grinder to remove this tip.



Step 2: Remove an additional 1/8" of material from the top of the spray arm as indicated by the



dotted line in the photo at left.

You can also use a grinder to remove this 1/8" of material.

Step 3: Continue mounting the spray arm to the bracket using the standard installation instructions.

**All spray arm installation questions should be directed to FMC at 816-550-6021**

## Supplemental Instructions for XP/White Bracket

**Mounting the spray arm on the XP style Keeton bracket requires a small modification to the spray arm. Please complete these steps before attempting to mount the arm to bracket.**



Step 1: Using a sharp utility knife trim the point off of the top of the spray arm as shown here. You can also use a grinder to remove this tip.



Step 2: Remove an additional 1/8" of material from the top of the



spray arm as indicated by the dotted line in the photo at left.

You can also use a grinder to remove this 1/8" of material.

Step 3: Continue mounting the spray arm to the bracket using the standard installation instructions.

**All spray arm installation questions should be directed to FMC at 816-550-6021**