

Maintenance Bulletin:
Airbag Wear Precaution Notice
May 2009



Application: Configuration 5 & 6 (JD 17xx/7200/7300 with high bracket)



In order to help prevent premature failure of the lift airbags, make sure the collar nut is installed as shown in the figure below. The flat of the hex collar nut should be tangent to the airbag surface.

Warning: Do not over torque the collar nut when adjusting its position. Torque to a maximum of 15 lb-ft.

