

20/20 SeedSense Installation on a Monosem Planter

To mount your Row Unit Modules on a Monosem planter, locate the hole in the goal post on the right side of the row unit (while facing forward from the back of the planter). Test mount the RUM upside down from the usual orientation. Clip off any tabs that are necessary for the RUM to sit flush with the goal post. Remaining tabs should help hold the RUM vertical. Use the supplied bolt and nut to mount the RUM and ladder tree. For further details, see pages 57-60 of the SeedSense Owner's Manual.



To mount your 5/8" Smart Pins, remove the 5/8" pivot arm pin from the row unit and replace it with the 5/8" Smart Pin as displayed at left below. Line up the bracket as shown and tighten screw as shown at right below to secure the bracket to the row unit. Now secure the opposite end of the 5/8" pin with a snap ring. See pages 66-71 of the SeedSense Owner's Manual for related instructions for a 5/8" pin installation.



Installing your Smart Connector:

If your Monosem Planter is equipped with a Kinze KPM or Monosem MPM monitor you will need to replace your planter harness and seed tube sensors and then install your Smart Connector according to Configuration 11 on page 52 of the 20/20 SeedSense Owner's Manual.

If your Monosem Planter is equipped with a Kinze KM or Dickey-john monitor, you will install your Smart Connector according to Configuration 2 on page 40 of the 20/20 SeedSense Owner's Manual.